



ENGLAND DNH WW Ltd

Phone......+ 44 1908 275 000 Fax.....+ 44 1908 275 100 E-mail......dnh@dnh.co.uk


GERMANY DNH GmbH

Phone... + 49 040 6569 30-0 Fax..... + 49 040 6569 30-30 E-mail...... dnh@dnh.de

<u>USA</u> DNH Speakers Inc

Phone......+ 1 484 494 5790 Fax.....+ 1 484 494 5793 E-mail..dnh@dnhspeakers.com

HP-6



Installation, Operation and Maintenance Procedures

- Fasten bracket with 1-3 screws, to wall or ceiling.
- To change the position of the loudspeaker, please adjust the bracket (by loosening / tightening the screws) as required.
- HP-6 is delivered with cable and the cable should be terminated in a suitable junction box.
- For optimum performance, always use the correct voltage / power and operate within the frequency limits as stated.
- This loudspeaker is supplied with two years warranty against defective materials and workmanship.